

## Frese ARCA Edge-serie

Installation guide - back plate version



[www.frese.eu/districtenergy](http://www.frese.eu/districtenergy)  

 +45 58 56 00 00

**Frese ARCA**

- x 1
- x 4
- x 4

**2**

**1**


**3**

## Frese ARCA Edge-serie


Installation guide - back plate version




4



6



5



**EN Safety Instructions:**

The manufacturer is not liable for any damage resulting from use other than in the designated application.

Such risk lies entirely with the user. Observance of the mounting instructions is considered as part of the product designated use.

**DE Sicherheitsanleitung:**

Der Hersteller übernimmt keine Haftung für Schäden, die aus nicht verwendungszweck-bezogener Handhabung resultieren.

Diese Risiken liegen ausschliesslich bei dem Anwender. Die Berücksichtigung dieser Montageanleitung ist als Teil des Verwendungszweckes des Produkts anzusehen.

**DK Sikkerhedsinstruktion:**

Fabrikanten forholder sig ikke ansvarlig for nogen form for skade forvoldt ved anden brug end den angivende applikation. Sådanne risici forbeholdes udelukkende brugeren. Det er vigtigt at overholde montagevejledningen for at sikre korrekt anvendelse af produktet.